



## SPATIQUE “Bromine” Chemical Recipe

### New Spa Initial Fill or Existing Spa Refill (based on 500 gal)

Step 1: Test H2O & adjust PH, Total Alkalinity & Calcium Hardness AS NEEDED.  
Step 2: Add 8 oz. of SPA BRIGHT (Removes unwanted minerals.)(Use 8 oz. for any size spa.)

Step 3: Add 2 oz. of CONTROL (Mineral Control & Clarifier)

### ALL SPAS WAIT 6 HOURS BEFORE PROCEEDING TO STEP 4

Step 4: fill Bromine feeder <sup>3</sup>/<sub>4</sub> full with Bromine. (BROM TABS)

Step 5: Add 2 oz. BROM START. (Establishes Bromine Reserve)

Step 6: Add 2 oz. SPA SHOCK. (Activates Bromide Reserve)

Step 7: Add 6 oz. PH HOLD. (Ph Stabilizer & H2O Softener) (OPTIONAL)

**NOTE: Calcium Hardness increaser does NOT come in startup kit.**

**\*\*See owner’s manual to set your spas filter to run 4 hrs. twice a day. This setting may need to be adjusted with season or usage, contact E.L.S. with any questions**

## Weekly Spa Chemical Maintenance

Step 1: Test For Bromine/ PH, Alkalinity& Calcium Hardness - Adjust As Needed.

Step 2: Refill Bromine Feeder with BROM TABS.

Step 3: Add 2 oz. SPA SHOCK.

Step 4: Add 1 oz. CONTROL.

Step 5: Add 1oz. SCUM OUT. (OPTIONAL)

Step 6: Add 1 oz. 5-IN-1 CLARIFIER. (For Optimum Water Clarity) (OPTIONAL)

**FOR SPAS USED 3+ TIMES WEEKLY, ADD SPA SHOCK 2 X WEEKLY.**

## RECOMMENDED ROUTINE SPA/CHEMICAL MAINTENANCE

1. Clean filters monthly with pressure hose spray.
2. Clean with Spray Cartridge Cleaner after each drain & fill.
3. Drain & refill spa 2 to 4 times a year; avoid doing during freeze.
4. To boost low bromine levels- add 2 oz. BROM START then wait 5 minutes & add 4 oz. SPA SHOCK.

5. **For unsightly or foul-smelling water; consider: Is H2O due to be drained? Are filters in need of changing or cleaning? Increase duration or frequency of filtration run cycles, has sanitizer level been maintained?**
6. **If you use "Well" water to top up your spa add 1 oz. of spa bright at the time of top up.**