



## SPATIQUE “FROG” System Chemical Recipe

### New Spa Initial Fill or Existing Spa Refill(based on 500 gal.)

Step 1: Test H2O & adjust Ph, Total Alkalinity& Calcium Hardness AS NEEDED.

Step 2: Add 8 oz. of SPA BRIGHT (Removes Unwanted Minerals)

Step 3: Add 1 oz. of CONTROL (Stain & scale control)

**ALL SPAS WAIT 6 HOURS BEFORE PROCEEDING TO STEP 4.**

Step 4: Install BLUE FROG & YELLOW or GREEN FROG Cartridges in housing.

Step 5: Add 2 oz. JUMP START PACK. (Establishes bromine reserve.)

Step 6: Add 2 oz. SPA SHOCK. (Activates Brom Start)

**NOTE: Calcium Hardness increaser does NOT come in Startup kit.**

**\*\*See owner’s manual to set your spas filter to run 4 hrs. twice a day. This setting may need to be adjusted with season or usage, contact E.L.S. with any questions**

## Weekly Spa Chemical Instructions

Step 1: Test For Bromine, Ph, Alkalinity& Calcium Hardness - Adjust As Needed.

Step 2: Check FROG BROMINE Cartridge. Replace As Needed.

Step 3: Add 2 oz. SPA SHOCK.

Step 4: Add 1 oz. CONTROL.

Step 5: Add 1oz. 5-IN-1 CLARIFIER. (For Optimum Water Clarity.) (OPTIONAL)

Step 6: Add 1oz. SCUM OUT (OPTIONAL)

**\*FOR SPAS USED 3+ TIMES WEEKLY, ADD SPA SHOCK 2 X WEEKLY. \***

## RECOMMENDED ROUTINE SPA/CHEMICAL MAINTENANCE

1. Replace BLUE MINERAL cartridge every 4 months.
2. Clean filters monthly with pressure hose spray.
3. Clean with SPRAY CARTRIDGE CLEANER after each drain.
4. Drain/refill spa 2-4 X a year; avoid doing during freeze.
5. To boost low bromine Level- Add 2 oz. BROM START or JUMP START then wait 5 minutes & add 4 oz. SPA SHOCK.

6. **For unsightly or foul-smelling water; consider: Is H<sub>2</sub>O due to be drained? are filters In need of changing/cleaning? Increase duration or frequency of filtration run cycles, has sanitizer level been maintained?**