

# EMERALD LeisureSource

## NATURE 2 SPA RECIPE

### START-UP INSTRUCTIONS FOR FRESH FILL

STEP 1: TEST PH, ALKALINITY AND CALCIUM HARDNESS ADJUST IF NEEDED  
STEP 2: ADD 8 OZ. **SPA BRIGHT**  
STEP 3: ADD 1 OZ. **CONTROL**

**ALL DOSES  
ARE PER  
250 GAL.**

\*ALL SPAS WAIT 6 – 12 HOURS BEFORE MOVING TO STEP 4

STEP 4: ADD 1 OZ. **SCUM OUT** (OPTIONAL)  
STEP 6: INSTALL **NATURE 2** CARTRIDGE  
STEP 7: ADD 1 TEASPOON **SANI SPA**

**NOTE: Calcium Hardness increaser does NOT come with Startup kit.**

### BEFORE EACH USE

STEP 1: ADD 1 TABLESPOON **SPA SHOCK** PER 250 GALLONS

### WEEKLY INSTRUCTIONS

STEP 1: TEST PH AND ALKALINITY AND ADJUST IF NEEDED  
STEP 2: ADD 1 OZ. **CONTROL**  
STEP 3: ADD 1 OZ. **SCUM OUT** (OPTIONAL)  
STEP 4: ADD 1 OZ. **5 IN 1 CLARIFIER** (OPTIONAL)  
STEP 5: ADD 3 TABLESPOONS **SPA SHOCK**

**ALL DOSES  
ARE PER  
250 GAL.**

**PH UP**-USED TO INCREASE THE PH LEVEL WHEN IT TESTS LOW

**PH DOWN**-USED TO DECREASE THE PH OR ALKALINITY LEVEL WHEN ONE OR BOTH TEST HIGH

**ALKALINITY UP**-USED TO INCREASE THE LEVEL OF ALKALINITY WHEN IT TESTS LOW

**HARDNESS CONTROL**-USED TO INCREASE THE LEVEL OF CALCIUM HARDNESS WHEN IT TESTS LOW

**FOAM AWAY**-USED WHILE YOU ARE IN THE SPA TO CONTROL ANY FOAMING DURING USE

**5 IN 1 CLARIFIER**-USED IN SOME CASES TO CLEAR CLOUDY WATER

**PH HOLD**-USED WHEN YOU FRESHLY FILL AFTER THE PH HAS BEEN PROPERLY BALANCED TO “LOCK” THE PH LEVEL

**CARTRIDGE RENU**-USED TO CHEMICALLY CLEAN YOUR FILTER CARTRIDGE BY SOAKING (SOAK OR SPRAY CLEANING RECOMMENDED EVERY 4-6 MONTHS)

**SPRAY CARTRIDGE CLEANER**-USED TO CHEMICALLY CLEAN YOUR FILTER CARTRIDGE BY COATING AND RINSING (SOAK OR SPRAY CLEANING EVERY 4-6 MONTHS)

# EMERALD LeisureSource

**SPA SURFACE CLEANER**-USED TO CLEAN THE ACRYLIC SHELL WHEN THE SPA IS  
EMPTY

**MULTI-SURFACE CLEANER DISINFECTANT**-VERY STRONG DISINFECTANT CLEANER  
USED TO CLEAN THE ACRYLIC SHELL WHEN THE SPA IS